

## **AT6104DM Spectrometer**

AT6104DM Immersion Multifunction Spectrometer is designed to monitor fresh water and sea water radiation levels, as well as bottom sediments.

All parameters are measured at depths of up to 150 m without prior sampling and sample preparation.

## **Operating principle**

Spectrometer unit in a temperature-and-shock-resistant watertight container from stainless steel detects gamma-radiation of monitored radionuclides.

Spectrometric data from detecting unit is sent via special cable to a PC and is displayed on its screen.

Instrumental spectra processing algorithms in PC Software are used for displaying of radioisotope composition data or certain radionuclide volume activity. Ambient gamma-radiation dose equivalent rate value in inspection point is determined by instrument spectrum analysis with "spectrum-dose" operational function.

The Spectrometer consists of: Detection unit, dedicated cable, software, etc.

Specification Specification	
Gamma radiation detector	Scintillator, NaI(TI) Ø63x63 mm
Registered gamma radiation energy range	50 keV3 MeV
Identified radionuclides	<sup>137</sup> Cs, <sup>134</sup> Cs, <sup>131</sup> I, <sup>40</sup> K, <sup>226</sup> Ra, <sup>232</sup> Th
Measurement range of specific activity in water for $4\pi$ measurement geometry $^{^{134}}\text{Cs}, ^{^{137}}\text{Cs}$ (Measurement time: 30 min) $^{^{40}}\text{K}$	31·10 <sup>6</sup> Bq/kg 2502·10⁴ Bq/kg
Measurement range of bottom sediments specific activity for $2\pi$ measurement geometry $$^{_{134}}\rm{Cs},$^{_{137}}\rm{Cs}$$	501·10⁵ Bq/kg
Intrinsic relative error of activity measurement	±30% max.
Measurement range of ambient radiation dose rate equivalent	0.01100 μSv/h
Intrinsic relative error of ambient dose equivalent rate measurement	±20% max.
Energy dependence for ambient gamma radiation dose rate equivalent measurement (100 keV3 MeV energy range)	±20% max.
Anisotropy in angular spacing ±120° relative to vertical axis (100 keV-3 MeV energy range)	±30%
Sensitivity to <sup>137</sup> Cs gamma radiation	1900 cps/μSv·h <sup>-1</sup>
Relative energy resolution for <sup>137</sup> Cs	8% max.
Maximum input statistical load	≥5·10⁴ s <sup>-1</sup>
Number of ADC channels	512 / 1024
Operation mode setup time	1 min
Integral nonlinearity	1% max.
Continuous run time in normal conditions	≥9 h
Measurement instability during continuous service	5% max.
Working temperature range	-20°C+50°C
Detection unit protection class	IP67 (Withstands static hydraulic pressure up to 1.50MPa)
GPS	GPS-receiver, integrated into HPC. Positioning accuracy ≥ 3 m
Connection to PC	RS 422
Overall dimensions	Ø125x633 mm
Detection unit weight	6.5 kg







